Logitech ConferenceCam CC3000e
Reference Guide

Starting a Video Call

You must connect to a computer to use this device!

1 Connect: Connect the USB cable to your PC, Mac or thin client. The camera and speakerphone will flash to show USB connection and, when completed, the camera head will rotate and the speakerphone will play a sound. Connect LCD to PC or Mac.

2 Start: Start your video application, ensuring that the CC3000e is selected for your camera, microphone and speaker options in the application.

3 Go: LEDs will light on the camera and speakerphone when video and audio are streaming, respectively.

LCD Display

NFC indicator

Mute button

Call Answer/End buttons

Far End control

Camera Preset control

Zoom buttons

Volume controls

Mute button

LED Call Activity

Bluetooth pairing

Call Answer/End buttons

Camera Zoom

Volume controls

Far End control

Camera Preset control

LED Call Activity

1. **Blue:** Call is active
2. **Blinking Blue:** Call is being received
3. **Blinking Blue in call:** Call has been put on hold from application
4. **Red:** Call is muted

LCD Call Activity

The LCD will display call activity as well as volume and connectivity status. Caller ID and call duration depend on application support. Please see Application Notes or Support for further information.

Device Controls

Bluetooth®: Hold down the *Bluetooth*® button until the blue LED on the speakerphone starts blinking. Go to Settings on your mobile device and complete the pairing. When paired, the *Bluetooth*® icon on the LCD will appear brighter.[1]

Camera Preset: Press and hold this button to define a new camera "home" position. The camera will return to this position when the call is started or by pressing the button once. You can change your home position at any time by repeating this step.

Far End Control: Press this button to pan, tilt and zoom the far-end CC3000e or BCC950 ConferenceCam[2]. Press again to toggle between far end and local cameras.

Logitech

UC for Real People