



Getting started with Logitech® Tablet Keyboard for iPad





Contents

English	3
繁體中文	5
한국어	7
www.logitech.com/support 	9




What's in the box




Product setup

Set up the keyboard

1



2




3

www.logitech.com/tablet-keyboard/support




1. Remove the keyboard from its case.
2. Pull the battery tabs on the keyboard to activate the batteries. The **On/Off** switch is already in the **On** position.
3. Visit www.logitech.com/tablet-keyboard/support for Bluetooth setup instructions for your tablet.

Using the keyboard FN key




User-friendly enhanced F-keys provide shortcuts to useful functions, such as Volume, Play and Next Track. To use the enhanced functions (blue icons), first press and hold the FN key; second, press the F-key you want to use.

Keyboard features



- | | | |
|--------------------------------------|---|--|
| 1. Home | 9. FN + - Volume down | 12. Battery icon
Green = full charge;
Red = battery power is low;
replace batteries |
| 2. cmd + space Switch language | 10. FN + = Volume up | 13. FN + Delete Lock/Unlock iPad |
| 3. FN + 5 Slideshow | 11. Bluetooth icon
Blinking green = device is discoverable and Bluetooth connection is pending;
Solid green = Bluetooth connection made; Red = no Bluetooth connection | 14. On/Off slider switch |
| 4. FN + 6 Show/Hide virtual keyboard | | 15. FN key |
| 5. FN + 7 Previous track | | 16. Search |
| 6. FN + 8 Play/Pause | | |
| 7. FN + 9 Next track | | |
| 8. FN + 0 Mute | | |





Help with setup: keyboard not working

- Is the keyboard turned on? Slide the keyboard Off/On switch to the On position.
- Restart the tablet.
- Is the Battery icon red? If it's red, replace the batteries.
- Re-establish the Bluetooth connection between the keyboard and your tablet.
Visit www.logitech.com/tablet-keyboard/support for Bluetooth setup instructions.




包裝內容




產品安裝

設定鍵盤

1



2




3

www.logitech.com/tablet-keyboard/support




1. 將鍵盤從其收納盒中取出。
2. 拉出鍵盤上的電池標籤以啟用電池。電源開啟關閉 (On/Off) 開關應已切換到開啟 (ON) 位置。
3. 請前往 www.logitech.com/tablet-keyboard/support，取得平板裝置的藍芽安裝指示。

使用鍵盤的 FN 鍵




使用便捷的增強式 F 功能鍵，可快速執行音量調整、播放以及下一首這類有用功能。若要使用增強式功能 (藍色圖示)，請先按住 FN 鍵，然後按下要使用的 F 功能鍵。

鍵盤功能



- | | | |
|---------------------|---|---|
| 1. 首頁 | 9. FN + - 音量減小 | 12. 電池圖示
綠燈 = 電量充足；紅燈 = 電池電力不足；請更換電池 |
| 2. cmd + 空格鍵 切換語言 | 10. FN + = 音量增大 | 13. FN + 刪除 鎖定/解鎖 iPad |
| 3. FN + 5 幻燈片播放 | 11. 藍芽圖示
閃爍綠燈 = 裝置在可偵測狀態並等待建立藍芽連線；恆亮綠燈 = 藍芽連線已建立；紅燈 = 沒有藍芽連線 | 14. 開啟/關閉切換開關 |
| 4. FN + 6 顯示/隱藏虛擬鍵盤 | | 15. FN 鍵 |
| 5. FN + 7 上一首 | | 16. 搜尋 |
| 6. FN + 8 播放/暫停 | | |
| 7. FN + 9 下一首 | | |
| 8. FN + 0 靜音 | | |





安裝說明：鍵盤沒有作用

- 鍵盤電源是否開啟？將鍵盤的電源開啟關閉 (Off/On) 開關切換到開啟 (On) 位置。
- 重新啟動平板裝置。
- 電池圖示變成紅色？如果變成紅色，請更換電池。
- 重新建立鍵盤與平板裝置之間的藍芽連線。請前往 www.logitech.com/tablet-keyboard/support，取得關於藍芽的安裝指示。




내용물




제품 설정

키보드 설정

1



2




3

www.logitech.com/tablet-keyboard/support




1. 케이스에서 키보드를 꺼냅니다.
2. 키보드의 배터리 탭을 당겨 배터리를 작동시킵니다. **ON/Off** 스위치는 이미 **ON** 위치로 설정되어 있습니다.
3. 태블릿에 대한 Bluetooth 설정 지침은 www.logitech.com/tablet-keyboard/support를 참조하십시오.

키보드의 FN 키 사용




사용이 편리하고 향상된 F 키는 볼륨, 재생 및 다음 트랙 등 유용한 기능에 대한 바로 가기를 제공합니다. 고급 기능(파란 아이콘)을 사용하려면 FN 키를 누른 채 사용하려는 F 키를 누릅니다.

키보드 기능



- | | | |
|-----------------------------|--|--|
| 1. 홈 | 9. FN + - 볼륨 줄이기 | 12. 배터리 아이콘
녹색 = 완전히 충전됨;
빨간색 = 배터리 전원이
부족함, 배터리 교체 |
| 2. cmd + space 언어 전환 | 10. FN + = 볼륨 높이기 | 13. FN + Delete iPad 잠금/잠금
해제 |
| 3. FN + 5 슬라이드 쇼 | 11. Bluetooth 아이콘
녹색으로 깜박임 = 장치가
검색 가능하고 Bluetooth
연결 대기 중임; 녹색(계속
켜짐) = Bluetooth 연결됨;
빨간색 = Bluetooth 연결
안 됨 | 14. 켜기/끄기 슬라이더 스위치 |
| 4. FN + 6 가상 키보드 표시/
숨기기 | | 15. FN 키 |
| 5. FN + 7 이전 트랙 | | 16. 검색 |
| 6. FN + 8 재생/일시 중지 | | |
| 7. FN + 9 다음 트랙 | | |
| 8. FN + 0 음소거 | | |



설치 도움말: 키보드가 작동하지 않을 때

- 키보드가 켜져 있습니까? 키보드 Off/On 스위치를 On 위치로 미십시오.
- 태블릿을 다시 시작하십시오.
- 배터리 아이콘이 빨간색입니까? 빨간색인 경우 배터리를 교체하십시오.
- 키보드와 태블릿 간의 Bluetooth 연결을 다시 설정하십시오. Bluetooth 설정 지침은 www.logitech.com/tablet-keyboard/support를 참조하십시오.



Logitech Addresses and Phone Numbers

Region	Sales Office Address	Technical Help
Logitech Far East Ltd. 羅技電子股份有限公司	6F-4, No. 123, Sec. 4, Pa-Teh Road, Taipei, Taiwan 臺北市八德路四段123號6樓之4 ☎ 886-2-2746-6601 ☉ 星期一至五，上午九時至 下午六時正	☎ 0800-012 300 (免付費) ☉ 星期一至五，上午九時至下午六時正
Logitech Singapore Pte Ltd.	1 Maritime Square #09-31/32 HarbourFront Centre (Lobby A) Singapore 099253 ☎ 65-6270 5515 ☉ Monday - Friday, 9am - 6pm	☎ 800-60-11-372 (Toll free for Singapore Only) ☎ 1800-88-0719 (Toll free for Malaysia Only) +(60) 3-2054-1886 (for Thailand, Indonesia, Indochina) ☉ Monday - Friday, 9am - 6pm
Logitech Australia Computer Peripherals Pty Ltd.	Level 2, 608-610 Liverpool Road, South Strathfield NSW 2136 Australia ☎ 61-2-9764 8300 ☉ Monday - Friday, 9am - 5pm (AEST)	☎ Australia: 1800-025-544 (Toll Free) ☉ Monday - Friday, 9am - 8pm (AEST) ☎ New Zealand: 0800-447-361 (Toll Free) ☉ Monday - Friday, 11am - 7pm (Auckland Time)
Logitech Electronic India PVT Ltd	MMTC House, Suite 603, 6th Floor C-22, Bandra Kurla Complex, Bandra East Mumbai 400 051, India ☎ 91-22-2657 1160 ☉ Monday - Friday, 9.30am - 6.30pm (IST)	☎ 000 800 600 1133 (Toll free) ☉ Monday - Friday, 9.30am - 6.30pm (IST)
Logitech Asia Pacific Ltd	Hong Kong Sales & Marketing 18/F, Cambridge House, Taikoo Place, 979 King's Road, Quarry Bay, Hong Kong. ☎ 852-2821-5900 ☉ Monday - Friday, 9am - 6pm	☎ 800-966-992 (Toll free) ☉ Monday - Friday, 9am - 6pm
www.logitech.com/support		

www.logitech.com

© 2011 Logitech, Inc. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Mac and the Mac logo are trademarks of Apple, Inc., registered in the U.S. and other countries. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. All other trademarks are the property of their respective owners.

621-000057.003