

Boombox

Wireless Bluetooth® Speaker
Setup Guide

Your UE Boombox



First-time setup

Pair your speaker to a Bluetooth-enabled tablet or smartphone.


On the UE Boombox

Power on the speaker. The status light blinks rapidly, indicating the speaker is ready to pair with a device.



On your device

Go to Settings and turn on Bluetooth. Tap UE Boombox in the list of nearby Bluetooth devices.



Set up more devices

Pair up to 8 Bluetooth devices with your speaker. (Any 3 devices can connect simultaneously.)


On the UE Boombox

Hold down the Bluetooth button until the status light starts blinking rapidly.



On your device

Go to Bluetooth Settings. Tap UE Boombox in the list of nearby Bluetooth devices.



Reconnect a device

After the initial pairing of your device with the UE Boombox, you can easily reconnect when the speaker is in Bluetooth range.

On your device

Go to Bluetooth Settings. Tap UE Boombox in the list of nearby Bluetooth devices.



Online support

Visit Product Central, your online destination for world-class support.

logitech.com/support/ueboombox

Find tutorials, troubleshooting tips, and guidelines for using UE Boombox with your Bluetooth-enabled devices.

Product Central is also home to lively forums that connect you to a global community of knowledgeable users.

Telephone support

Canada	+1 866-934-5644
United States	+1 646-454-3200

Boombox

Haut-parleur sans fil Bluetooth®
Guide d'installation

Votre UE Boombox



Première configuration

Couplez votre haut-parleur à une tablette ou à un smartphone compatible Bluetooth.


Sur la UE Boombox

Mettez le haut-parleur sous tension. Le témoin d'état clignote rapidement, indiquant que le haut-parleur est prêt pour être couplé à un dispositif.



Sur votre dispositif

Accédez aux paramètres Bluetooth et activez le mode Bluetooth. Dans la liste des dispositifs Bluetooth détectés, sélectionnez UE Boombox.



Configuration de plusieurs dispositifs

Vous pouvez coupler jusqu'à huit dispositifs Bluetooth à votre haut-parleur. Vous pouvez même connecter trois dispositifs simultanément.


Sur la UE Boombox

Maintenez le bouton Bluetooth enfoncé jusqu'à ce que le témoin d'état commence à clignoter rapidement.



Sur votre dispositif

Accédez aux paramètres Bluetooth. Dans la liste des dispositifs Bluetooth détectés, sélectionnez UE Boombox.



Reconnexion d'un dispositif

Après le premier couplage de votre dispositif à la UE Boombox, vous pouvez facilement vous y reconnecter lorsque le haut-parleur est en mode Bluetooth.

Sur votre dispositif

Accédez aux paramètres Bluetooth. Dans la liste des dispositifs Bluetooth détectés, sélectionnez UE Boombox.



Support en ligne

Visitez les pages Produits en ligne pour trouver toute l'assistance dont vous avez besoin.

logitech.com/support/ueboombox

Vous y trouverez des didacticiels, des conseils de dépannage, ainsi que des instructions liées à l'utilisation de votre UE Boombox avec vos dispositifs compatibles Bluetooth.

Les pages Produits vous donnent également accès à des forums utiles qui vous permettent d'entrer en contact avec une communauté mondiale d'utilisateurs expérimentés.

Support téléphonique

Canada +1 866-934-5644
Etats-Unis +1 646-454-3200