



Folio m1




Setup Guide


## Contents

English. . . . .	3
한국어 . . . . .	7
<b>www.logitech.com/support</b>  . . . . .	11

## Know your product




1. iPad mini holder
2. Camera hole
3. Cut out for easy access to iPad mini controls
4. Protective folio
5. Hook
6. Product documentation




## Setting up and using the folio with your iPad mini

### Setting up your folio


1. Open the folio and insert the corner of your iPad mini next to the power button into the holder.



2. Insert the side of your iPad mini into the hook:




3. Push the opposite corner of your iPad mini down into the other holder:



### Using your iPad mini

Opening the folio wakes your iPad mini:




Closing the folio puts your iPad mini into sleep mode.


## Two viewing positions

The folio provides two viewing positions—one for viewing media and another for browsing.

To view media, place your iPad mini at the angle you feel comfortable with:




To browse, fold your folio back along its spine:




## Detaching your iPad mini

To detach your iPad mini from the folio, bend back one of the iPad mini holder corners:



Your iPad mini is then released:



## Visit Product Central

There's more information and support online for your product. Take a moment to visit Product Central to learn more about your new folio.

[www.logitech.com/support/folio-m1](http://www.logitech.com/support/folio-m1)

Browse online articles for setup help, usage tips, and information about additional features.

Connect with other users in our Community Forums to get advice, ask questions, and share solutions.

Find a wide selection of content including:

- Tutorials
- Troubleshooting
- Support community
- Online documentation
- Warranty information
- Spare parts (when available)

## Troubleshooting


**My iPad mini won't stand in the media position.**

- Make sure your iPad mini is inserted in the iPad mini holder correctly, and that the viewing angle is between 50° and 65°.


**My iPad mini won't wake when I open the folio, and doesn't go into sleep mode when I close it.**

- Make sure your iPad mini is inserted in the iPad mini holder the right way round.

## 제품 설명




1. iPad mini 홀더
2. 카메라 홀
3. iPad mini 컨트롤에 쉽게 액세스할 수 있는 홈
4. 보호 폴리오
5. 후크
6. 제품 설명서




## iPad mini에서 폴리오 설정 및 사용

### 폴리오 설정


1. 폴리오를 연 후 홀더에 iPad mini 전원 버튼 옆 부분의 모서리를 끼워 넣습니다.



2. iPad mini 측면을 후크에 끼워 넣습니다.




3. iPad mini의 반대편 모서리를 다른 홀더에 밀어 넣습니다.



### iPad mini 사용

폴리오를 열면 iPad mini가 켜집니다.




폴리오를 닫으면 iPad mini가 슬립 모드로 전환됩니다.




## 두가지 방법의 거치

폴리오는 미디어 감상과 탐색용의 두 가지 뷰를 제공합니다.

미디어 감상 시에는 편안한 각도로 iPad mini를 거치합니다.




탐색 시에는 측면을 따라 폴리오를 뒤로 접습니다.




## iPad mini 분리

폴리오와 iPad mini를 분리하려면 iPad mini 홀더 모서리 중 하나를 뒤로 구부립니다.



그런 다음 iPad mini를 빼냅니다.



## Product Central 방문

온라인상에서 제품에 대한 추가 정보와 지원을 확인할 수 있습니다. Product Central에는 폴리오에 관한 자세한 내용이 나와 있습니다.

[www.logitech.com/support/folio-m1](http://www.logitech.com/support/folio-m1)

설정 도움말, 사용 팁 및 추가 기능에 관한 정보를 온라인으로 찾아볼 수 있습니다.

Community Forums에서 다른 사용자와 교류하면서 질문과 조언을 교환하고 솔루션을 공유할 수 있습니다.

다음과 같은 다양한 내용을 확인할 수 있습니다.

- 사용 지침
- 문제 해결
- 지원 커뮤니티
- 온라인 문서
- 보증 정보
- 예비 부품(해당되는 경우)

## 문제 해결

**iPad mini를 미디어 위치에 세울 수 없습니다.**

- iPad mini가 iPad mini 홀더에 제대로 삽입되었고 시야각이 50°와 65° 사이인지 확인하십시오.

**폴리오를 열어도 iPad mini가 켜지지 않고 닫아도 슬립 모드로 전환되지 않습니다.**

- iPad mini를 iPad mini 홀더에 제대로 삽입했는지 확인하십시오.

---

[www.logitech.com/support/folio-m1](http://www.logitech.com/support/folio-m1)



Taiwan	0800-012-300
Korea	00798-601-8207
Hong Kong	800-966-992
Australia	1-800-025-544
India	800-600-1133
Malaysia	1800-88-0719
Singapore	800-6011-372
New Zealand	0800-447-361



[www.logitech.com](http://www.logitech.com)

© 2013 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Apple and iPad are trademarks of Apple Inc., registered in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

621-000205.002