



TYPE-S

Thin and light protective keyboard case
For Samsung GALAXY Tab S 10.5

TYPE-S

aK1060 键盘保护套
适用于 Samsung GALAXY Tab S 10.5



Setup Guide | 设置指南

Contents

[English](#)


3

[简体中文](#)

14

www.logitech.com/support/type-s


Know your product




Setting up the keyboard case

Getting started


1. Open the keyboard case and push your Samsung GALAXY Tab S 10.5 into the tablet holder:



2. Push your Samsung GALAXY Tab S 10.5 down into the hook:




3. Move the keyboard case into the typing position by lifting the back of the protective case and sliding the hook forwards until it aligns with the magnet:



Connecting your keyboard and tablet

The keyboard case links to your tablet via a Bluetooth connection. The first time you use the keyboard case, you must pair the keyboard with your tablet.





1. Turn on the keyboard:

The status light blinks blue (fast blink) to indicate that the keyboard is discoverable, ready for pairing with your tablet. The first time you turn on the keyboard it remains discoverable for 15 minutes.

If the status light turns red, charge the battery. For more information, see “Charging the keyboard battery.”

2. Make sure your tablet's Bluetooth feature is on.

From a Home screen, touch  **Apps** →  **Settings** → **Network connections** section, and turn on the **Bluetooth switch**.

3. Pair the keyboard case with your tablet.



(i) In your tablet's **Bluetooth** settings page, select “TYPE-S” in the list of **Available devices**.

(ii) When prompted, enter the PIN displayed using the case keyboard.


When successful connection is made, the status light turns solid blue for a short time, and then turns off.

Connecting to another tablet

1. Make sure the keyboard is turned on.
2. Make sure your tablet's Bluetooth feature is on.

From a Home screen, touch  **Apps** →  **Settings** → **Network connections** section, and turn on the **Bluetooth switch**.

3. Press the Bluetooth Connect button:



The status light blinks blue (fast blink) to indicate that the keyboard is discoverable, ready for pairing with your tablet. The keyboard is discoverable for 3 minutes.

4. Pair the keyboard case with your tablet.

(i) In your tablet's **Bluetooth** settings page, select "TYPE-S" in the list of **Available devices**.

(ii) When prompted, enter the PIN displayed using the case keyboard.

When successful connection is made, the status light turns solid blue for a short time, and then turns off.


Using the keyboard case

Two viewing positions

The keyboard case provides two viewing positions—one for typing and another for browsing.


To type:

1. Move the tablet holder into the typing position, aligning it with the built-in magnet to secure it:



Typing position


2. Turn on the keyboard:



If the status light turns red, charge the battery. For more information, see “Charging the keyboard battery.”

If you don't use the keyboard for a while in the typing position, it enters sleep mode automatically. Pressing any key wakes it.

To browse, place the tablet holder in the browsing position:



Browsing position

You can switch off the keyboard if you want to conserve battery power.

Status light indicators

Bluetooth and battery status light

Light	Description
Blinking green	The battery is charging.
Green	The battery is charged (more than 10%).
Red	Battery power is low (less than 10%). Recharge the battery.
Blinking blue	Fast: The keyboard is in discovery mode, ready for pairing. Slow: The keyboard is trying to reconnect to your Samsung GALAXY Tab S 10.5.
Solid blue	Bluetooth pairing or reconnection is successful.


Function keys

**FN + Back: Esc****FN + 1: Lock screen**
Lock or unlock the tablet screen**FN + 2: Web browser****FN + 3: Mail****FN + 4: Calendar****FN + 5: Music****FN + 6: Previous track****FN + 7: Play/Pause****FN + 8: Next track****FN + 9: Mute****FN + 0: Volume down****FN + -: Volume up****FN + =: Print Screen****FN + Backspace: Forward delete****FN + Tab: Show all apps****FN + Caps Lock:**
Quick panel/Notifications**FN + X: Cut****FN + C: Copy****FN + V: Paste****FN + Left cursor: Home****FN + Right cursor: End****FN + Up cursor: Page Up****FN + Down cursor: Page Down****FN + Search: Voice search**
Use your voice to send messages, make calls, and more**FN + Right Alt: Android™ menu****FN + Android home: Switch applications****FN + spacebar: Switch language**

Note:

- To select a function key, press and hold the FN key, and then press the key indicated above.

Charging the keyboard battery



If the status light is red the keyboard case battery needs to be charged.

1. Plug one end of the micro-USB cable into the charging port, and the other end into a USB port on your computer.


The status light blinks green as the battery charges.

2. Charge the battery until the status light turns solid green.

Battery information

- A fully charged battery provides about three months of use when the keyboard is used about two hours a day.
- Charge the battery if the status light turns red briefly after the keyboard turns on.
- When not in use, turn off the keyboard to conserve battery power.
- The keyboard enters sleep mode automatically if not used for a while in the typing position. Press any key to wake it.

Battery disposal at product end of life




1. Pry off top cover of keyboard with screwdriver.
2. Detach battery from circuit board and remove battery.
3. Dispose of your product and its battery according to local laws.


When you've finished using the keyboard case

Detaching your tablet

1. Release your tablet from the hook:




2. Slide your tablet out of the tab holders:



Your tablet is then released.

Storing your tablet for travel

1. Insert your tablet in the tablet holder.
2. Close the keyboard case:



Visit Product Support

There's more information and support online for your product. Take a moment to visit Product Support to learn more about your new keyboard case.

Browse online articles for setup help, usage tips, and information about additional features.

Connect with other users in our Community Forums to get advice, ask questions, and share solutions.

Find a wide selection of content including:



- Tutorials
- Troubleshooting
- Support community
- Online documentation
- Warranty information
- Spare parts (when available)

Go to:

www.logitech.com/support/type-s

Troubleshooting

The keyboard does not work


- Press any key to wake the keyboard from sleep mode.
- Turn the keyboard off and then back on.
- Recharge the internal battery. For more information, see “Charging the keyboard battery.”
- Verify that Bluetooth is turned on in your tablet's settings (⌘ Apps →  **Settings** → **Network connections** section → **Bluetooth**).
- Verify that “TYPE-S” is paired with your tablet (⌘ Apps →  **Settings** → **Network connections** section → **Bluetooth**).
- Re-establish Bluetooth connection between the keyboard and your tablet by selecting “TYPE-S” in the list of **Available devices**. The status light on your keyboard turns solid blue when Bluetooth connection is established.

What do you think?

Thank you for purchasing our product.
Please take a minute to tell us what you think of it.

www.logitech.com/ithink


了解您的产品




设置键盘保护套

入门指南


1. 打开键盘保护套，将 Samsung GALAXY Tab S 10.5 推入平板电脑支架：



2. 将 Samsung GALAXY Tab S 10.5 向下推入挂钩：




3. 提起保护套背面，向前滑动挂钩，直到挂钩与磁体对齐，将键盘保护套移动至打字位置：



连接键盘和平板电脑

键盘保护套与平板电脑之间通过蓝牙进行连接。首次使用键盘保护套时，必须将键盘与平板电脑进行配对。



1. 开启键盘：

状态指示灯闪烁蓝灯（快速闪烁），表示键盘处于可被搜索状态，可与平板电脑进行配对。首次开启键盘后，键盘将保持可被搜索状态 15 分钟。

如果状态指示灯变为红灯，请为电池充电。有关详细信息，请参见“为键盘电池充电”。

2. 确保平板电脑的蓝牙功能已开启。

在主屏幕上触控  应用程序 →  设置 → 网络连接部分，然后开启蓝牙开关。

3. 将键盘保护套与平板电脑配对。

- (i) 在平板电脑的蓝牙设置页面，从可用设备列表中选择“TYPE-S”。
- (ii) 根据提示，通过保护套键盘输入显示的 PIN。


成功连接后，状态指示灯将在短时间内变为稳定的蓝光，然后熄灭。

连接到其他平板电脑

1. 确保键盘处于开启状态。
2. 确保平板电脑的蓝牙功能已开启。

在主屏幕上触击  应用程序 →  设置
→ 网络连接部分，然后开启蓝牙开关。

3. 按下蓝牙连接按钮：



状态指示灯闪烁蓝光（快速闪烁），表示键盘处于可被搜索状态，可与平板电脑进行配对。键盘在 3 分钟内将处于可被搜索状态。

4. 将键盘保护套与平板电脑配对。
 - (i) 在平板电脑的**蓝牙**设置页面，从**可用设备**列表中选择“TYPE-S”。
 - (ii) 根据提示，通过保护套键盘输入显示的 PIN。

成功连接后，状态指示灯将在短时间内变为稳定的蓝光，然后熄灭。


使用键盘保护套

两种放置方式

键盘保护套提供两种放置方式：一种用于输入，一种用于浏览。


如要打字：

1. 请将平板电脑支架放到适合输入的位置，将其与内置的磁体对齐以固定到位：



打字位置

2. 开启键盘：



如果状态指示灯变为红灯，请为电池充电。有关详细信息，请参见“为键盘电池充电”。

在处于输入位置时，如果有一段时间未使用，则键盘会自动进入休眠模式。按任意键可将其唤醒。

如要浏览，请将平板电脑支架置于浏览位置：



浏览位置

如您想节省电池电量，可关闭键盘。

状态指示灯

蓝牙和电池状态指示灯

指示灯	说明
闪烁绿灯	电池正在充电。
绿灯	电池有电 (>10%)。
红灯	电量不足 (<10%)。为电池充电。
闪烁蓝灯	快速: 键盘处于可被搜索状态, 已准备好可以进行配对。 缓慢: 键盘正在尝试重新连接您的 Samsung GALAXY Tab S 10.5。
稳定蓝灯	蓝牙配对或重新连接成功。


功能键

**FN + Back: Esc****FN + 1: 锁屏**
锁定或解锁平板电脑屏幕**FN + 2: 网络浏览器****FN + 3: 邮件****FN + 4: 日历****FN + 5: 音乐****FN + 6: 上一曲目****FN + 7: 播放/暂停****FN + 8: 下一曲目****FN + 9: 静音****FN + 0: 调低音量****FN + -: 调高音量****FN + 退格键: 删除前一个字符****FN + Tab: 显示全部应用程序****FN + Caps Lock:**
快速面板/通知**FN + X: 剪切****FN + C: 复制****FN + V: 粘贴****FN + 左光标: Home****FN + 右光标: End****FN + 向上光标: Page Up****FN + 向下光标: Page Down****FN + 搜索: 语音搜索**
通过语音发送消息，拨打电话以及执行其他操作**FN + 右 Alt: Android™ 菜单****FN + Android 主页:**
切换应用程序**FN + 空格键: 切换语言**

请注意:

- 要选择功能键，请按住 FN 键，然后按上方显示的键。

为键盘电池充电



如果状态指示灯变成红灯，则说明键盘保护套的电池需要充电。

1. 将微型 USB 连接线的一端插入充电端口，将另一端插入电脑上的 USB 端口。


电池充电过程中，状态指示灯将闪烁绿灯。

2. 为电池充电，直到状态指示灯变为稳定的绿灯为止。

电池信息

- 如果键盘每天使用约两个小时，则满电量电池可使用约三个月时间。
- 在开启键盘之后，如果状态指示灯短暂亮起红灯，请为电池充电。
- 不使用时，请关闭键盘以节省电池电量。
- 在处于输入位置时，如果有一段时间未使用，则键盘会自动进入休眠模式。按任意键即可将其唤醒。

电池废弃处置




1. 用螺丝刀撬开键盘的顶盖。
2. 从电路板上分离电池，取出电池。
3. 根据当地法律对产品和电池进行弃置。


键盘保护套使用完毕后

卸下平板电脑

1. 将平板电脑从挂钩上取下：




2. 将平板电脑滑离平板电脑支架：



之后便能够将平板电脑取出。

旅行时收纳平板电脑

1. 将平板电脑插入平板电脑支架。
2. 合上键盘保护套：



访问“产品支持”

我们的网站提供有关于本产品的详细信息和支持服务。请抽时间访问“产品支持”，了解关于新键盘保护套的更多信息。

浏览在线文章，查看安装帮助、使用技巧以及关于更多功能的信息。

通过“社区论坛”与其他用户交流，获得建议，提出问题，分享解决方法。

“社区论坛”涵盖众多内容，其中包括：





- 教程
- 疑难解答
- 支持社区
- 在线文档
- 保修信息
- 备用部件（若有供应）

打开：

www.logitech.com/support/type-s

疑难解答

键盘不工作

- 按任意键即可将键盘从休眠模式中唤醒。
- 将键盘关闭，然后再将其重新开启。
- 为内置电池充电。有关详细信息，请参见“为键盘电池充电”。
- 确保在平板电脑的设置中已将蓝牙开启（ 应用程序 →  设置 → 网络连接部分 → 蓝牙）。
- 确保“TYPE-S”已同平板电脑配对（ 应用程序 →  设置 → 网络连接部分 → 蓝牙）。
- 重新建立键盘与平板电脑间的蓝牙连接，方法为：在可用设备列表中选择“TYPE-S”。蓝牙连接建立后，键盘上的状态指示灯将变成稳定蓝灯。

您对本产品有何感想？

感谢您购买罗技产品。
请拨冗告诉我们您的意见。

www.logitech.com/ithink



www.logitech.com

www.logitech.com/support/type-s

© 2014 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Samsung, GALAXY and Tab S 10.5 are trademarks of Samsung Electronics Co., Ltd. Android, Google Play and Google Maps are trademarks of Google, Inc. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2014 年罗技。保留所有权利。罗技、罗技标志、Logitech 和其他罗技商标均归罗技所有，并或已注册。Samsung、GALAXY 和 Tab S 10.5 是 Samsung Electronics Co., Ltd. 的商标。Android、Google Play 和 Google Maps 是 Google, Inc. 的商标。所有其他商标均是各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。

621-000351.002