

# AnyAngle™

Protective case with any-angle stand


iC1051 拥有任意角度支架的保护套



Setup Guide | 设置指南

# Contents / 目录

## Know your product



- 1. Camera and microphone hole
- 2. Volume control buttons
- **3.** Holes for access to charging port and speakers
- 4. On/off button
- 5. iPad holder
- **6.** Cut out for access to headphone socket
- 7. Foldable hinge
- 8. Protective cover
- 9. Product documentation




## Setting up and using the folio with your iPad

### Setting up your folio

1. Open the folio and insert your iPad into the protective shell:




2. Push your iPad down:



### Using your iPad

When you want to start using your iPad, flip the cover open:



Opening the folio wakes your iPad.


When you're finished, closing the folio puts your iPad into sleep mode:




Keep the folio closed for travel.

#### Folding and adjusting


When open, fold the cover down to make a stand for your iPad:



You can adjust the viewing angle in the range 20° - 70° for FaceTime® video calling, browsing or typing:




You can also lay your folio flat to hold your iPad easily with one hand:



When flat, you can turn your iPad to portrait orientation for easy reading.

#### Detaching your iPad

To detach your iPad from the folio, bend back one of the iPad holder corners:



Your iPad is then released:



### Visit Product Support

There's more information and support online for your product. Take a moment to visit Product Support to learn more about your new protective case.

Browse online articles for setup help, usage tips, and information about additional features.

Connect with other users in our Community Forums to get advice, ask questions, and share solutions.

At Product Support, you'll find a wide selection of content including:

- Tutorials
- Troubleshooting
- Support community
- · Online documentation
- · Warranty information
- Spare parts (when available)

Go to:

www.logitech.com/support/anyangle-i6

## Troubleshooting

My iPad won't wake when I open the folio, and doesn't go into sleep mode when I close it.


 Make sure your iPad is inserted in the iPad holder the right way.
When your iPad is inserted correctly, the camera on your iPad should line up with the camera and microphone hole on the folio (see "Know your product"). In landscape orientation, the Home button should be on your right-hand side.

## What do you think?


Please take a minute to tell us. Thank you for purchasing our product.

## www.logitech.com/ithink

## 了解您的产品



- 1. 摄像头和麦克风孔位
- 2. 音量控制按钮
- 3. 充电端口和音箱开孔
- 4. 开启/关闭按钮
- 5. iPad 支架
- 6. 耳机插口开孔
- 7. 可折叠转轴
- 8. 保护盖
- 9. 产品文档




## 在 iPad 上设置和使用保护套

#### 设置您的保护套

1. 打开保护套, 将 iPad 插入保护壳:




2. 向下推入 iPad:



### 使用 iPad

想要开始使用 iPad 时,请翻开保护套:




打开保护套即可唤醒 iPad。 使用完毕后, 闭合保护套 iPad 即进入休 眠模式:




旅行时确保保护套处于闭合状态。

### 折叠与调整


保护套处于开启状态时,将其向下折叠,即形成一个可供 iPad 使用的支架:



您可以在 20° - 70° 的范围内调整观 看角度,以便进行 FaceTime 视频通话、 网页浏览或打字输入:




此外,您还可以水平放置保护套,单手轻松操作 iPad:




水平放置时,您可以将 iPad 转为纵向,畅想阅读乐趣。

### 卸下 iPad

如要将 iPad 从保护套卸下,将其中一个 iPad 支架的角向后弯曲:



之后便能够将 iPad 取出:



### 访问"产品支持"

我们的网站提供有关于本产品的详细信息 和支持服务。请抽时间访问"产品支持", 了解关于新保护套的更多信息。

浏览在线文章,查看安装帮助、使用技巧 以及关于更多功能的信息。

通过"社区论坛"与其他用户交流,获得建议,提出问题,分享解决方法。 "产品支"提供了广泛的内容选择:

- 教程
- 疑难解答
- 支持社区
- 在线文档
- 保修信息
- 备用部件 (若有供应)

### 访问:

www.logitech.com/support/anyangle-i6

### 疑难解答

### 打开保护套无法唤醒 iPad,闭合保护套也 无法使其进入休眠模式。

• 确保将 iPad 以正确的方式插入 iPad 支架中。

正确插入 iPad 后, iPad 上的摄像头应对准保护套上的摄像头和麦克风孔位 (参阅"了解您的产品")。横向放置时,Home 键应位于您的右侧。

## 您对本产品有何感想?

欢迎拨冗告知我们。 感谢您购买罗技产品。

## www.logitech.com/ithink



www.logitech.com

## www.logitech.com/support/anyangle-i6

© 2014 Logitech. All rights reserved. Logitech, the Logitech logo, 罗技, and other Logitech marks are owned by Logitech and may be registered. Apple, iPad, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. The Bluetooth\* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice

版权所有 © 2014 年罗技。罗技、罗技标志、Logitech 和其他罗技商标均归罗技所有,并或已注册。Apple 和 iPad 是 Apple Inc. 在美国和其他国家注册的商标。蓝牙™ 文字标志为 Bluetooth SIG, Inc. 所有的注册商标,罗技对此类 标志的所有使用均已获得授权。所有其它商标均是其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担 任何责任。本手册中包含的信息如有更改,恕不事先通知。

621-000440.002