


SMARTDOCK + EXTENDER BOX | 智能底座 + 扩展盒

Setup Guide | 设置指南




logitech 罗技™

3 ENGLISH


7 简体中文

Disassemble SmartDock


1



2




3






Plug in and install Surface


4




Reassemble SmartDock



Remove base




Plug HDMI cable into SmartDock for content sharing from HDMI sources. Connect SmartDock and the extender box with 5-in-1 cable.




Reattach base

10




Power on Surface

12




Plug cables into the extender box

11




拆卸智能底座


1



2




3






插入并安装 Surface


4




重新装配智能底座



拆下基座




将 HDMI 线缆插入智能底座, 实现 HDMI 源内容共享。
使用五合一线缆将智能底座和延长器盒相连。




重新装上基座

10




接通 Surface 电源

12



将线缆插入延长器盒

11



产品中有害物质的名称及含量

根据中国<< 电子电气产品有害物质限制使用标识要求>>

有害物质 Hazardous Substances						
部件名称 Parts Name	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电缆线/电源 Cable/Adaptor	X	O	O	O	O	O
电路板组件 PWAs	X	O	O	O	O	O
塑料/其它部件 Plastic/Others parts	O	O	O	O	O	O
玻璃部件 Glass parts	X	O	O	O	O	O
金属部件 Metal parts	X	O	O	O	O	O
电池 Battery	X	O	O	O	O	O
本表格依据 SJ/T 11364 的规定编制。 O = 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 X = 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。 表中标有 " X " 的所有部件均符合欧盟 RoHS Recast 法规 - 2011/65/EU 指令。 此表显示"罗技科技有限公司"的电子电气产品部件中何处存在这些有害物质。请注意，并非内装产品都包含上述所有部件。 注：环保使用期限的参考标准，取决于产品正常工作的温度和湿度等条件。						



© 2017 Logitech. Logitech, Logi, 罗技 and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Microsoft, Windows Vista, Windows, and the Windows logo are trademarks of the Microsoft group of companies. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2017 年罗技。罗技、Logi 和其他罗技商标均归罗技所有，并或已注册。所有其他商标均是其各自所有者的财产。Microsoft、Windows Vista、Windows 和 Windows 标志是 Microsoft 集团公司的商标。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。

WEB-621-000017.002