SPOTLIGHT PRESENTATION REMOTE 罗技® SPOTLIGHT 远程演示


Setup Guide | 设置指南



logitech 罗技®

- ENGLISH
- 5 简体中文

SETUP



FEATURES



LED

Instant feedback on battery and connectivity status.

2 Pointer

- Press and hold to hightlight, magnify and control the on-screen cursor.
- Simple press to open video/links.
- Double press to toggle pointer modes.

3 Next

- Simple press to navigate forward.
- Press and hold to use custom functions like volume control.

4 Back

- Simple press to navigate backward.
- Press and hold to use custom functions like volume control.

5 Haptic feedback


Receive silent timer notifications and battery alerts.

6 Rechargeable USB-C

Up to 3 month battery life on a single charge via USB-C charging cable.

logitech.com/support/spotlight

LOGITECH PRESENTATION SOFTWARE



Timer: Track presention time and set vibration alerts

Pointer: Toggle pointer modes and customize the size of your hightlight and magnify overlays.

Custom control: Use Logitech Presentation to configure Spotlight for blanking the screen, gesture-controlled scrolling, volume adjustments, and more.

Onboarding: Learn how to use Spotlight with an immersive tour.

Sleep mode protection: Spotlight keeps your computer awake while you present.

Battery alerts: Receive an on-screen notification when your battery is running low. **Operating range:** Move and present freely from up to 30 meters/100 feet.


Universal compatibility: Works with Keynote, Powerpoint, PDF, Google Slides, Prezi. Compatible with Windows® 7* or later and OS X 10.10 or later.

*Windows 7 compatibility with USB-receiver only.

Dual connectivity: Simply plug in the USB receiver or pair via Bluetooth®. To pair, press and hold pointer and back buttons for two seconds

Fast charge: One minute gives you three hours of presentation.

设置 1 Logicool.co.jp/presentation 下载并安装软件



功能



1 LED

立即反馈电量与连接状态。

2 指针

- 按住可突出显示、放大和控制屏幕光标。
- 按一下可打开视频/链接。
- 按两下可切换指针模式。

3 下一页

- 按一下向后导航。
- 按住可使用自定义功能, 例如音量控制。

4 上一页

- 按一下向前导航。
- 按住可使用自定义功能, 例如音量控制。

5 触觉反馈

接收静音的定时器通知与电量警告。

6 可充电 USB-C

通过 USB-C 充电线充电, 一次充电可用 3 个月。

?) logitech.com/support/spotlight

5

LOGITECH PRESENTATION 软件



定时器: 跟踪演讲时间并设置振动提醒。

指针: 切换指针模式,和自定义突出显示和放大区域大小。

自定义控制: 使用 Logitech Presentation 为 Spotlight 配置黑屏、手势滚动、音量调节等的控制方式。

上手教程: 通过浸入式教程了解如何使用 Spotlight。

防止进入睡眠模式: Spotlight 可在演讲过程中保持计算器始终处于唤醒状态

电量警告: 在电量不足时接收屏幕通知。

工作范围: 可在 30 米 (100 英尺) 范围内自由 地移动和演讲。

强大的兼容性: 兼容 Keynote、Powerpoint、PDF、Google Slides、Prezi。 兼容 Windows® 7*或更高版本,以及 OS X 10.10 或更高版本。
*只有在使用 USB 接收器时才与 Windows 7 兼容。

双重连接技术: 仅需插入 USB 接收器, 或通过*蓝牙*配对。要配对, 同时按住指针和上一页按钮, 并持续两秒钟。

快速充电: 充电一分钟, 可演讲三小时。

© 2017 Logitech. Logitech, Logi, 罗技 and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners.

版权所有© 2017 年罗技。罗技、Logi 和其他罗技商标均归罗技所有,并或已注册。所有其他商标均是其各自所有者的财产。

WEB-621-000891.002