



FLIGHT RUDDER PEDALS

Professional Rudder Pedals with Toe Brake Simulation Controller
带脚尖制动模拟控制器的专用方向舵踏板

USER GUIDE | **用户指南**

[logitechG.com](https://logitechg.com)

FLIGHT | 飞行



YOKE SYSTEM
控制器系统

RUDDER PEDALS
方向舵踏板

INSTRUMENT PANEL
仪表盘



MULTI PANEL
多功能面板

RADIO PANEL
无线电面板

SWITCH PANEL
开关面板



Build your whole cockpit with our modular, interchangeable system.
用模块化的可互换式系统构建整个驾驶舱。

4 ENGLISH

7 简体中文

GETTING STARTED

REMOVABLE FOOT RESTS

ADJUSTABLE PEDALS

3-stage pedal length adjustment

ADJUSTABLE TENSION

Adjust the resistance to suit any plane



INTRODUCTION

Logitech G Flight Rudder Pedals are solid 3-axis rudder pedals designed to maximize realism by enabling foot control of the rudder and brakes function in flight simulation PC Games. The Rudder Pedals work with any Logitech G Flight products.

THE USB CABLE

Insert the Logitech G Flight Rudder Pedals USB plug into one of your PC's free USB sockets.

INSTALLATION FOR WINDOWS® 10, WINDOWS® 8.1 AND WINDOWS® 7

DRIVER INSTALLATION

- 1 Visit logitech.com/support/rudder-pedals to download the latest drivers and software for your operating system.
- 2 **With device disconnected**, follow the onscreen instructions to complete the installation.
- 3 At the Driver Setup screen, **only when prompted**, insert USB cable into one of your computer's USB ports, then click **Next**.
- 4 At the Driver Setup screen, click **Next** to test your controller.
- 5 When the Logitech Controller screen appears, test the controls to verify device operation. After the test, click OK.

SOFTWARE INSTALLATION

- 1 In the Software Setup screen, click Next and a pop-up box will ask if you “want to trust software from Logitech.” Click yes, then click Next.
- 2 After installation, you have the option to Run Profile Editor, which will show you the programming environment. To skip the Profile Editor now, uncheck the box and click Finish to complete installation.

TECHNICAL SUPPORT

Online Support: support.logitech.com

入门指南


可拆卸足跟撑垫

可调踏板

踏板长度支持 3 段调整

可调张力

调整阻力, 适合各款飞机



简介

罗技 G 飞行方向舵踏板是一款旨在提高真实感的坚固耐用的 3 轴方向舵踏板, 支持在飞行模拟 PC 游戏中用脚控制方向舵和制动功能。方向舵踏板可配合各款罗技 G 飞行产品使用。

USB 接线

将罗技 G 飞行方向舵踏板 USB 插入 PC 中的一个可用 USB 插口中。

WINDOWS® 10、WINDOWS® 8.1 和 WINDOWS® 7 的安装

驱动程序安装

- 1 访问 logitech.com/support/rudder-pedals, 下载面向您操作系统的最新驱动程序和软件。
- 2 在设备连接情况下, 按屏幕说明完成安装。
- 3 在“驱动程序安装”画面中, **只有在出现提示时**, 再将 USB 线插入计算机 USB 端口, 然后单击**下一步**。
- 4 在“驱动程序安装”画面中, 单击**下一步**来进行控制器测试。
- 5 在“罗技控制器”画面弹出时, 测试各个控件, 检查设备能否正常作业。在测试完成后, 单击“确定”。

软件安装

- 1 在“软件安装”画面中, 单击“下一步”, 一个弹出框随即出现, 询问是否“要信任罗技 G 的软件”。单击“是”, 然后单击“下一步”。
- 2 在安装后, 您可选择“运行配置文件编辑器”, 可借此显示编程环境。要在此时跳过“配置文件编辑器”, 取消选中复选框, 并单击“完成”来完成安装。

技术支持

在线支持: support.logitech.com

CLOSER TO REALITY

LOGITECH FLIGHT PRODUCTS

更接近现实

罗技飞行产品

logitech 



SWITCH PANEL
IN-COCKPIT CONTROLS

开关面板

驾驶舱内控制



MULTI PANEL
IN-COCKPIT CONTROLS

多功能面板

驾驶舱内控制



RADIO PANEL
IN-COCKPIT CONTROLS

无线电面板

驾驶舱内控制

PERFECT PARTNERS
理想搭配产品



© 2017 Logitech. Logitech, Logi, 罗技 and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners.

版权所有 © 2017 年罗技。罗技、Logi 和其他罗技商标均归罗技所有，并或已注册。所有其他商标均是其各自所有者的财产。

WEB-621-000946.002

