



	iPod Nano (3G)	iPod classic	iPod touch	iPhone	Older iPods
					iPod with video iPod nano (1G/2G) iPod (4G) iPod mini
Pure-Fi Dream™					
Pure-Fi Anywhere™ 2					
Pure-Fi Anywhere™					
Pure-Fi Elite™					
AudioStation™					
Pure-Fi Express™ AudioStation Express™					
mm50					
mm32					
FreePulse™ Wireless Headphones					
X-240 Speakers					

Other PC Speakers + Pure-Fi Mobile™

All PC speakers and Pure-Fi Mobile™ work with all iPods. Plug the source cable into the iPod headphone jack. (For iPhone, a 3rd party adapter is required.*)

* When you connect your iPhone to a speaker with an iPod dock, your iPhone will present you with the option to go into Airplane Mode, which turns off the communication capability of the iPhone while it's connected to the speaker. If you choose not to enter Airplane Mode, you can make and receive calls, but you may experience some occasional audio interference while listening to music.