



Left Click



Right Click



Middle Click



Scroll  
Vertical + Horizontal

## STANDARD MOUSE



Double tap with 2 fingers

Windows 8 // Start Screen (Metro)  
Windows 7 // Start Menu

Mac with Software // Mission Control



Swipe with 2 fingers

Windows 8 // Back and Forward  
Windows 7 // Back and Forward

Mac with Software // Back and Forward



Left edge swipe

Windows 8 // Display the App bar



Right edge swipe

Windows 8 // Display the Charms bar

## OS NAVIGATION



Double tap with 1 finger

Windows 8 with Software // Show and Hide desktop  
Windows 7 with Software // Show and Hide desktop

Mac with Software // Smart zoom

## ADVANCED GESTURES

**SOFTWARE REQUIRED**

SMOOTHER PERFORMANCE

CUSTOMIZABLE SETTINGS

OPTIMAL GESTURES