





Logitech® G90 Optical Gaming Mouse  
Setup Guide






1



2




Your mouse is ready for game play. If you would like to customize your mouse, refer to the next section.

您的滑鼠已妥善設定，可立即用於進行遊戲。如果您想要自訂滑鼠，請參閱下方的說明。

이 마우스는 게임 플레이를 할 준비가 되어 있습니다. 마우스를 커스터마이징하려면 다음 섹션을 참조하십시오.

3


[www.logitech.com/support/g90](http://www.logitech.com/support/g90)



To customize your mouse, download the free Logitech Gaming Software at [www.logitech.com/support/g90](http://www.logitech.com/support/g90).

若要自訂滑鼠，請到 [www.logitech.com/support/g90](http://www.logitech.com/support/g90) 下載免費的羅技遊戲軟體。

마우스를 커스터마이징하려면 [www.logitech.com/support/g90](http://www.logitech.com/support/g90)에서 로지텍 게이밍 소프트웨어(무료)를 다운로드하십시오.



## Product features

1. Left button
2. Right button
3. Scroll wheel/middle button<sup>1</sup>
4. DPI button<sup>2</sup>

<sup>1</sup> Middle button function can vary by operating system.

<sup>2</sup> Pressing the DPI button repeatedly allows you to cycle through three DPI settings: 1000, 1750, or 2500. Use a smaller DPI setting (e.g., 1000 DPI) for slower movements like sniping and a higher setting (e.g., 2500 DPI) for quicker movements.

## 產品功能

1. 左鍵
2. 右鍵
3. 滾輪/中鍵<sup>1</sup>
4. DPI 按鈕<sup>2</sup>

<sup>1</sup> 中鍵功能會視作業系統而有不同。

<sup>2</sup> 重複按下 DPI 按鈕可讓您在三種 DPI 設定之間循環切換：1000、1750 或 2500。在進行狙擊之類的緩慢動作時，請使用較低的 DPI 設定（例如，1000 DPI），需要較快速的移動動作時請使用較高的設定（例如，2500 DPI）。

## 제품 기능

1. 왼쪽 버튼
2. 오른쪽 버튼
3. 스크롤 휠/가운데 버튼<sup>1</sup>
4. DPI 버튼<sup>2</sup>

<sup>1</sup> 가운데 버튼 기능은 운영 체제별로 다를 수 있습니다.

<sup>2</sup> DPI 버튼을 반복해서 누르면 1000, 1750, 2500의 3가지 DPI 설정이 교대로 표시됩니다. 스나이핑과 같은 느린 동작의 경우에는 더 낮은 DPI 설정(예: 1000DPI)을 사용하고, 빠른 동작에서는 더 높은 설정(예: 2500DPI)을 사용하십시오.

## Help with setup

- Check the mouse USB cable connection. Try the mouse USB cable in another USB port on the computer. Use only a powered USB port.
- Try rebooting the computer.
- If possible, test the mouse on another computer.
- Visit [www.logitech.com/support/g90](http://www.logitech.com/support/g90) for more information.

## 安裝說明

- 請檢查滑鼠 USB 連接線的連接。嘗試將滑鼠 USB 連接線插入電腦的其他 USB 連接埠。請使用供電式 USB 連接埠。
- 嘗試重新啟動電腦。
- 如果可能的話，請在另一台電腦上測試此滑鼠。
- 如需詳細資訊，請造訪 [www.logitech.com/support/g90](http://www.logitech.com/support/g90)。

## 설치 도움말

- 마우스 USB 케이블 연결을 확인합니다. 마우스 USB 케이블을 컴퓨터의 다른 USB 포트에 연결해 봅니다. 전원이 공급되는 USB 포트만 사용합니다.
- 컴퓨터를 재부팅해 봅니다.
- 다른 컴퓨터에서 마우스를 테스트해 봅니다.
- 자세한 내용은 [www.logitech.com/support/g90](http://www.logitech.com/support/g90)을 참조하십시오.

[www.logitech.com/support/g90](http://www.logitech.com/support/g90)



<u>Taiwan</u>	<u>0800-012-300</u>
<u>Korea</u>	<u>00798-601-8207</u>
<u>Hong Kong</u>	<u>800-966-992</u>
<u>India</u>	<u>800-600-1133</u>
<u>Malaysia</u>	<u>1800-88-0719</u>
<u>Singapore</u>	<u>800-6011-372</u>





[www.logitech.com](http://www.logitech.com)

© 2014 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

621-000325.002