Logitech®

Getting started with Logitech® Wireless Mouse M280





English. 3


繁體中文 9

한국어 15

What's in the box









Set-up


1




2




3



Mouse features





1. Left and right buttons
2. Scroll wheel
   Press the wheel down for middle click. Function can vary by software application:
   - In most Internet browsers, the middle click will close browser tabs by clicking anywhere on the tab, without the need of clicking the X.
   - In most Internet browser, the middle click on a link will open the link in a new tab.
   - In most Internet browsers, when you middle-click a folder located in your bookmarks/favorites bar, each website in the folder will open in its own tab.
   - In many applications, if you click and hold the middle button, you will then be able to scroll in any direction by dragging the mouse.
3. Battery LED
   Flashes red when battery power is low. If the battery is not low, the LED indicator will turn green for 10 seconds when the mouse is switched on or after deep-sleep mode recovery.
4. On/Off slider switch
   The mouse will go into sleep mode if no movement is detected. We recommend switching the mouse off to avoid accidental clicking when carrying it around and to further save battery life.
5. Battery door release

Sleep mode

The mouse will go into sleep mode after 10 seconds of inactivity and can be woken up by clicking or moving the mouse. The mouse will go into deep sleep mode after 5 minutes of inactivity and can be woken up by clicking.

unifying™

The receiver with this mouse does not integrate with the Logitech® Unifying technology. However, the mouse itself is Unifying-ready and can be used with any Logitech® Unifying receivers you may already have.


Logitech® Unifying technology connects up to six compatible Logitech mice and keyboards to the same receiver, using only one USB port for multiple devices.
To learn more, visit www.logitech.com/unifying.


Troubleshooting


Mouse is not working

- Is the mouse powered on?
- Is the receiver securely plugged into a USB port? Try changing USB ports.
- If the receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
- Check the orientation of the battery inside the mouse.
- Try a different surface. Remove metallic objects between the mouse and the receiver.
- Try moving the receiver to a USB port closer to the mouse.

包裝內容










設定

1




2







3



滑鼠功能





1. 左右按鍵
2. 滾輪
   按下滾輪可執行按下中鍵功能。功能會視軟體應用程式而有不同：
   - 在大部分的網際網路瀏覽器中，在標籤的任意地方按下中鍵可關閉瀏覽器標籤，而不必按下 X。
   - 在大部分的網際網路瀏覽器中，在連結上按下中鍵會在新標籤中開啟連結。
   - 在大部分的網際網路瀏覽器中，在「書籤/我的最愛」列的資料夾上按下中鍵，會在其各自的標籤頁中開啟資料夾中的每一個網站。
   - 在許多應用程式中，如果按住中鍵不放，則可以拖曳滑鼠往任何一個方向捲動。
3. 電池 LED 指示燈
   當電池電力不足時會閃爍紅燈。如果電池電力充足，則 LED 指示燈會在滑鼠電源開啟時，或從深度休眠模式復原時，亮起綠燈 10 秒鐘。
4. 開啟/關閉切換開關
   如果沒有偵測到任何移動動作，滑鼠會進入休眠模式。在攜帶滑鼠到處移動，或想要進一步節省電池壽命時，建議關閉滑鼠電源以避免誤觸按鍵。
5. 電池蓋釋放鈕

休眠模式

如果 10 秒鐘內不使用，滑鼠會進入休眠模式，按下滑鼠按鍵或移動滑鼠可將其喚醒。如果 5 分鐘內不使用，滑鼠會進入深度休眠模式，按下滑鼠按鍵可將其喚醒。

unifying™

此滑鼠提供的隨附接收器與羅技® Unifying 技術並未整合相容。但滑鼠本身是可使用 Unifying 技術的裝置，可以搭配您已擁有的任何羅技® Unifying 接收器使用。


在同一個接收器上透過羅技® Unifying 技術，只使用一個 USB 連接埠即可連接多達 6 個相容的羅技滑鼠或鍵盤。
若要瞭解更多詳細資訊，請瀏覽：www.logitech.com/unifying。


疑難排解


滑鼠無法使用

- 滑鼠是否已打開電源？
- 接收器是否已穩固地插入到 USB 連接埠？ 請嘗試更換 USB 連接埠。
- 如果接收器是插在 USB 集線器上，請嘗試將其直接插入到電腦上的 USB 連接埠。
- 檢查滑鼠內部電池的方向。
- 在不同的表面上進行嘗試。將滑鼠和接收器之間的金屬物移走。
- 嘗試將接收器移到較接近滑鼠的 USB 連接埠上。

내용물









설정


1




2




3



마우스 특징





1. 왼쪽/오른쪽 버튼
2. 스크롤 휠
   가운데 클릭을 하려면 휠을 아래로 누르십시오. 기능은 소프트웨어 응용 프로그램별로 다를 수 있습니다.
   - 대부분의 인터넷 브라우저 창을 닫을 때 X 를 클릭할 필요 없이 이 탭의 가운데를 클릭하면 브라우저가 닫힙니다.
   - 대부분의 인터넷 브라우저에서 링크를 가운데 클릭하면 새 탭에 이 링크가 열립니다.
   - 대부분의 인터넷 브라우저에서 책갈피/즐겨찾기 표시줄에 있는 폴더를 가운데 클릭하면 이 폴더의 각 웹사이트가 고유한 탭에서 열립니다.
   - 여러 응용 프로그램에서 가운데 클릭을 계속 실행한 상태로 마우스를 끌어 어느 방향으로나 스크롤할 수 있습니다.
3. 배터리 LED
   배터리 전원 부족 시 빨간색으로 깜빡입니다. 배터리가 부족하지 않으면 마우스를 켜는 경우 또는 딥 슬립 모드 복구 후 LED 표시기가 10초간 녹색으로 켜집니다.
4. 켜기/끄기 슬라이더 스위치
   동작이 감지되지 않으면 마우스가 슬립 모드로 전환됩니다. 휴대 시 실수로 클릭하지 않게 방지하고 배터리 수명을 보호할 수 있도록 마우스를 끄는 것이 좋습니다.
5. 배터리 도어 해제

슬립 모드

10초 동안 움직임이 없으면 마우스는 슬립 모드로 전환되고 마우스를 클릭하거나 움직이면 해제됩니다. 5분 동안 움직임이 없으면 마우스는 딥 슬립 모드로 전환되고 클릭하면 해제됩니다.

unifying™

이 마우스의 수신기는 로지텍의 Unifying 기술을 사용하지 않으나, 마우스 자체로는 Unifying을 사용할 수 있기 때문에 이미 보유하고 있는 모든 로지텍 Unifying 수신기와 함께 사용할 수 있습니다.

로지텍 Unifying 기술을 통해 하나의 USB 포트에 최대 6개의 호환 가능한 로지텍 마우스 및 키보드를 연결하십시오.
자세한 내용을 알아보려면 www.logitech.com/unifying을 방문하십시오.

문제 해결

마우스가 작동되지 않을 때

- 마우스 전원이 켜져 있습니까?
- 수신기가 USB 포트에 안정적으로 연결되어 있습니까? 다른 USB 포트에 연결해 보십시오.
- 수신기가 USB 허브에 연결되어 있으면 컴퓨터 USB 포트에 직접 연결해 보십시오.
- 마우스 내부의 배터리 방향을 점검하십시오.
- 다른 표면에 사용해 보십시오. 마우스와 수신기 사이에 있는 금속 물체를 제거하십시오.
- 수신기를 마우스와 가까운 USB 포트로 옮겨 보십시오.

M/N:C-U0010

Rating: 5V ⎓ 100mA


Approval No.: ETA-2250/2012/WRLO

CMIIT ID: 2012DJ7188









KCC-CRM-DZL-C-U0010



MADE IN CHINA

www.logitech.com/support/M280

© 2014 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Registered in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

621-000356.002