

SCREEN SHARE

Setup Guide | 设置指南




logitech 罗技™


English 3

简体中文 7

WHAT'S INCLUDED




1. Indicator LED
2. USB
3. HDMI
4. Cable Mount
5. Hook and loop fastener
6. Screen Share Application*



*www.logitech.com/support/screenshareapp


SET UP YOUR PRODUCT



3



4



5



SET UP YOUR PRODUCT

1. Connect the Screen Share USB cable into your host computer.
Plug your HDMI cable (not included) into other side of Screen Share.
2. Plug the HDMI cable into your content sharing device.
3. Screen Share will automatically enumerate as a USB camera device when an HDMI source is connected. Show shared content on an external display using the Screen Share application or your video streaming application of choice.
4. Prevent accidental HDMI disconnections with the cable mount.
Attach the mount onto a flat surface via the adhesive or screws.
Secure the HDMI cable to the mount with the zip tie.
5. Use the hook and loop fastener to secure Screen Share onto a solid surface.

SCREEN SHARE APPLICATION

Logitech offers a simple and easy-to-use application for streaming content from Screen Share. Installed on the host computer, this application will launch a window with the shared content once an HDMI source is connected. The Screen Share application is recommended for the best experience, but not required. Please visit **www.logitech.com/support/screenshareapp** for more information and download.

VISIT PRODUCT CENTRAL


Discover your product's full potential. Get valuable information and usage tips by browsing easy-to-use FAQs. Find answers to product questions and get help setting up your product. Downloaded the Screen Share application to enhance your product experience. To enjoy all the benefits of your Logitech product, visit **www.logitech.com/support/screenshare** and take advantage of Logitech's wide range of useful support services:

- Product information
- Troubleshooting
- Firmware upgrades
- Support community
- Software downloads
- In-box documentation
- Warranty information
- Spare parts (if available)



TROUBLESHOOTING TIPS

Please visit **www.logitech.com/support/screenshare** for troubleshooting tips and information on software.

包装内容




1. LED 指示灯
2. USB
3. HDMI
4. 连接线底座
5. 钩环扣
6. 传屏器应用程序*



[*www.logitech.com/support/screenshareapp](http://www.logitech.com/support/screenshareapp)


设置您的产品




3



4



5



设置您的产品

1. 将传屏器 USB 连接线连接至您的主机。将您的 HDMI 连接线（不随附）插入传屏器另一端。
2. 将 HDMI 线缆插入您的内容共享设备。
3. 连接至 HDMI 源后, 传屏器将自动列为 USB 摄像头设备。使用传屏器应用程序或您所选的视频播放应用程序在外部显示屏上显示共享的内容。
4. 防止 HDMI 与连接线底座意外断开。使用粘合剂或螺丝将底座连接至平坦表面。只用束线带将 HDMI 连接线固定至底座。
5. 使用钩环扣将传屏器固定至固体表面。

传屏器应用程序

罗技提供易于使用的应用程序, 可流畅播放共享内容。该应用程序安装在主机, 连接至 HDMI 源后, 即会投射出具有共享内容的窗口。为提升产品体验, 建议使用传屏器应用程序, 但不要求。请访问 www.logitech.com/support/screenshareapp 获取更多信息并下载。

访问产品中心

全面发掘产品潜力。请浏览常见问答集, 了解相关的实用信息和技巧。查询有关产品问题的答案及产品安装帮助。下载传屏器应用程序提升您的产品体验。如需尽享罗技产品的所有优势, 请访问 www.logitech.com/support/screenshare 充分利用罗技体贴周到的支持服务:

- 产品信息
- 疑难解答
- 固件升级
- 支持社区
- 软件下载
- 包装盒内文件
- 保修信息
- 备用部件 (若有供应)

故障排除技巧

请访问 www.logitech.com/support/screenshare 了解更多软件故障排除技巧。

© 2017 Logitech. Logitech, 罗技, Logi and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2017 年罗技。罗技、Logi 和其他罗技商标均归罗技所有，并或已注册。所有其它商标均是其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。

WEB-621-001029.003