

# RUGGED COMBO 2

## Do's and Don'ts



### DO

- Re-attach the keyboard to the case and close the Rugged Combo before carrying. This will help to protect the keyboard and iPad screen.
- Ensure there are no objects between iPad and the keyboard when closing the screen.
- If using Logitech Crayon or Apple Pencil, store in the stylus holder when not in use.
- Keep all parts and connectors clean and free of debris at all times.

### DO NOT

#### CARRYING AROUND

- Transport or carry the iPad separate from the keyboard cover.
- Place the keyboard into your bag or binder by itself.
- Put anything between the iPad case and keyboard cover, putting supplies (ex: pens, pencils, folders) in between the iPad and keyboard cover can cause damage.

#### USING

- Remove any parts of the case or disassemble Rugged Combo2. All parts of the Rugged Combo 2 are meant to protect the iPad and will only be effective if all components are used and assembled correctly.
- Remove the iPad from the case to access the headphone jack or charging ports. The case has the necessary openings to use headphones and charge.
- Use the stylus holder for anything other than a Logitech Crayon or Apple Pencil.
- Spill liquids onto the keyboard.
- Use the keyboard on an uneven surface.

