SLIM COMBO

Setup guide

設定指南 | 설치 가이드

logitech®

English 3

繁體中文 7

한국어 11

SLIM COMBO

Setup guide

KNOW YOUR PRODUCT





SETTING UP THE CASE

1. Insert iPad into iPad holder, and press down until it clicks into place. Make sure the camera and microphone match up to the openings on the iPad holder.
2. If you have a stylus or digital pencil, slide it into the holder on the side of the case.



ESTABLISHING THE CONNECTION

To pair your keyboard case with your iPad:

1. Switch on the power button. If the LED status light is red, charge the keyboard.
2. On your iPad, make sure *Bluetooth*® is on.
   – Select *Settings* > *Bluetooth* > *On*.
   – Select "iPad" from the Devices menu.
3. Press the *Bluetooth*® connect button on the keyboard for 2 seconds until the status light blinks. The keyboard is discoverable for 3 minutes.
4. If your iPad requests a PIN, enter it using the keyboard (not on the iPad), then press ENTER.
5. When a successful connection is made, the status light stays on for a short time, then turns off.



FOUR VERSATILE MODES

1. Typing mode
Pull out the stand on the back of the iPad holder to the desired angle. Attach the keyboard, and place the iPad case on a flat surface to start typing.



2. Viewing mode
Detach the keyboard. Pull out the stand on the back of the iPad holder to the desired angle.



3. Studio mode
Detach the keyboard. Pull out the stand on the back of the iPad holder until the iPad is in a comfortable drawing position.



4. Reading mode
Detach the keyboard. Close the stand on the back of the iPad holder, and hold in portrait orientation for the optimum reading position.



DETACHING YOUR iPAD

1. To detach your iPad from the case, lay it on a flat surface.
2. Press down on one corner of the iPad holder to release one side of the iPad; repeat on the opposite corner.
3. Lift the iPad from the bottom to release it from the case.



LED LIGHT INDICATORS

LED Behavior	Status
Blinking green	Battery is charging
Solid green	Battery is fully charged (100%)
Red	Battery level is low (less than 10%), recharge the battery
Blinking white	Fast: Keyboard is in discovery mode, ready for pairing Slow: Keyboard is trying to reconnect to iPad
Solid white	*Bluetooth*® pairing or reconnection is successful

SHORTCUT KEYS



CHARGING THE BATTERY

If the status light is red, the keyboard folio battery needs to be charged.

1. Plug one end of the micro-USB cable into the charging port and the other end into a USB port on your computer.

   Alternatively, you can use a USB charger, provided the power output rating is no more than 5V-500mA.

   The status light blinks green as the battery charges.
2. Charge the battery until the status light turns solid green.

BATTERY INFORMATION

- A fully charged battery provides about 3 months of use when the keyboard is used about two hours a day.
- Charge the battery if the status light turns red briefly after the keyboard turns on.
- When not in use, turn off the keyboard to conserve battery power.
- The keyboard enters sleep mode automatically if not used for a while in the typing position. Press any key to wake it.

BATTERY DISPOSAL

1. Pry off top cover of keyboard with screwdriver.
2. Detach battery from circuit board and remove battery.
3. Dispose of your product and battery according to local laws.



SLIM COMBO
設定指南

瞭解您的產品



logitech®

繁體中文

設定保護殼

1. 將 iPad 插入 iPad 插槽，然後向下按壓直到其卡入定位。確認攝影機與麥克風對準 iPad 插槽的開孔。
2. 如果有觸控筆或數位鉛筆，將其滑入保護殼側方的插槽。



建立連線

若要將鍵盤保護殼與 iPad 進行配對：

1. 將電源按鈕切換到開啓位置。如果 LED 狀態指示燈亮起紅燈，請為鍵盤充電。
2. 在 iPad 上，確認藍牙功能已開啓。
   - 依次選擇「設定」>「藍牙」>「開啓」。
   - 在「裝置」功能表中選擇「iPad」。
3. 按下鍵盤上的藍牙連線按鈕 2 秒不放，直到狀態指示燈閃爍。鍵盤在 3 分鐘內將處於可偵測狀態。
4. 如果 iPad 要求輸入 PIN，則使用鍵盤進行輸入 (不是在 iPad 上輸入)，然後按下 ENTER 鍵。
5. 成功連線後，狀態指示燈會在短時間內變為恆亮，然後熄滅。



四種多工便利模式

1. 打字模式

將 iPad 插槽背面的支架拉出到想要的角度。連接鍵盤並將 iPad 保護殼放置在平坦的表面上，開始打字。



2. 檢視模式

卸下鍵盤。將 iPad 插槽背面的支架拉出到想要的角度。



3. 工作室模式

卸下鍵盤。將 iPad 插槽背面的支架拉出到可舒適在 iPad 上描繪的位置。



4. 閱讀模式

卸下鍵盤。闔上 iPad 插槽背面的支架，以直立方式將其放置在最佳的閱讀位置。



卸下 IPAD

1. 若要從保護殼取下 iPad，請將保護殼於平坦表面上攤平。
2. 按壓 iPad 插槽的一角使 iPad 的一側露出；在反方向角落重複相同動作。
3. 從下方拿起 iPad，使其脫離保護殼。



LED 指示燈

LED 指示燈行為	狀態
閃爍綠燈	電池正在充電
穩定綠燈	電池已充滿 (100%)
紅燈	電池電量過低 (低於 10%)，請更換電池
閃爍白燈	快速：鍵盤處於可偵測狀態，已準備好可以進行配對 緩慢：鍵盤正在嘗試重新連線到 iPad。
穩定白燈	藍牙配對或重新連線成功

快捷鍵



為電池充電

如果狀態指示燈變成紅燈，則表示鍵盤折疊保護組的電池需要充電。

1. 將 Micro-USB 連接線的一端插入充電埠，將另一端插入電腦上的 USB 連接埠。
   或者，您也可以使用輸出功率不超過 5V-500mA 的 USB 充電器進行充電。
   電池充電過程中，狀態指示燈將閃爍綠燈。
2. 為電池充電，直到狀態指示燈變為穩定的綠燈為止。

電池資訊

- 如果鍵盤每天使用約兩個小時，則充滿電量的電池可使用約 3 個月時間。
- 在開啓鍵盤電源之後，如果狀態指示燈短暫亮起紅燈， 請為電池充電。
- 不使用時，請關閉鍵盤電源以節省電池電量。
- 處於輸入位置時，如果有一段時間未使用，則鍵盤會自動進入休眠模式。按下任意鍵即可將其喚醒。

電池棄置

1. 使用螺絲刀撬開鍵盤的頂蓋。
2. 從電路板上分離電池，取出電池。
3. 根據當地法律對產品與電池進行棄置。



SLIM COMBO
설치 가이드

제품 설명



케이스 착용하기

1. iPad를 iPad 홀더에 끼운 후 딱 들어맞을 때까지 눌러줍니다. 카메라와 마이크가 케이스의 정확한 위치에 있는지 확인합니다.
2. 스타일러스 펜 또는 디지털 펜슬이 있다면 케이스 옆 홀더에 끼워서 보관하세요.



연결 다시 설정하기

키보드 케이스와 iPad 페어링 방법

1. 전원 버튼을 켜십시오. LED 상태 표시등이 빨간색으로 바뀌면 키보드를 충전하십시오.
2. iPad에서 *Bluetooth*®가 켜져 있는지 확인합니다.
   - 설정 > Bluetooth > 켬을 선택합니다.
   - 장치 메뉴에서 "iPad"를 선택합니다.
3. 상태 표시등이 깜박거릴 때까지 키보드의 *Bluetooth*® 연결 버튼을 2초 동안 길게 누르십시오. 키보드가 3분 동안 연결 가능한 블루투스 기기를 검색합니다.
4. iPad에 PIN을 입력하라는 메시지가 나타나면 키보드(iPad에 조작하지 않음)를 사용하여 PIN을 입력하고 ENTER를 누릅니다.
5. 연결이 되면 상태 표시등이 잠시 켜졌다가 꺼집니다.



다양한 4가지 모드

1. 타이핑 모드

iPad 홀더 뒷면의 스탠드를 당겨 원하는 각도로 조절하십시오. 키보드를 연결하고 평평한 표면 위에 iPad 케이스를 놓은 후 타이핑을 시작하십시오.



2. 보기 모드

키보드를 분리합니다. iPad 홀더 뒷면의 스탠드를 당겨 원하는 각도로 조절하십시오.



3. 스튜디오 모드

키보드를 분리합니다. iPad 홀더 뒷면의 스탠드를 당겨 화면을 기울이고 드로잉하기 편안한 위치로 조절하십시오.



4. 북모드

키보드를 분리합니다. iPad 홀더 뒷면의 스탠드를 닫고 독서에 최적화된 세로 모드로 iPad를 사용하세요.



IPAD 분리

1. iPad를 분리하기 위해 케이스를 평평한 바닥에 두십시오.
2. iPad 홀더의 한 쪽 모서리를 눌러 iPad의 다른 한 쪽을 들어올립니다. 반대편 모서리도 똑같이 합니다.
3. iPad의 아래쪽을 들어올려 케이스와 분리합니다.



LED 표시등

LED 동작	상태
녹색으로 깜빡임	배터리 충전 중
녹색으로 유지	배터리 충전 완료 (100%)
빨간색	배터리 부족 (10% 미만). 배터리를 다시 충전하십시오.
흰색으로 깜빡임	빠르게: 블루투스 기기 검색 중, 페어링 준비 완료 느리게: iPad 연결 중
흰색으로 유지	*Bluetooth*® 페어링 또는 연결 완료

바로 가기 키



배터리 충전

상태 표시등이 빨간색이면 배터리를 충전해야 합니다.

1. 마이크로 USB 케이블로 케이스와 컴퓨터를 연결합니다.
   또는 5V-5oomA 이하 전원 출력의 USB 충전기를 사용할 수 있습니다.
   배터리를 충전하는 동안 상태 표시등이 녹색으로 깜빡입니다.
2. 상태 표시등이 녹색으로 계속 켜질 때까지 배터리를 충전합니다.

배터리 정보

- 배터리 완충시, 키보드를 하루 두 시간 정도 사용할 경우 최대 2개월간 사용 가능합니다.
- 키보드를 켰을 때 상태 표시등에 빨간색 불이 점등되면 배터리를 충전하십시오.
- 사용하지 않을 때는 키보드 전원을 끄고 배터리를 절약하십시오.
- 미사용시 키보드는 자동으로 슬립 모드로 전환됩니다. 다시 타이핑을 시작하면 재작동됩니다.

배터리 폐기

1. 드라이버로 키보드의 위 커버를 엽니다.
2. 회로 기판에서 배터리를 분리하여 빼냅니다.
3. 해당 지역의 법규에 따라 제품과 배터리를 폐기합니다.



© 2018 Logitech, Logi, 罗技 and the Logitech Logo are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries.

版權所有 © 2018 年羅技。Logi 和羅技標誌為 Logitech Europe S.A. 及/或其附屬公司在美國和其他國家的商標或註冊商標。

© 2018 Logitech, Logi, Logitech 로고는 미국와 기타 국가에서 로지텍 유럽 및/또는 그 계열사의 상표 또는 등록 상표입니다.

WEB-621-001169.002