


S150 USB STEREO SPEAKERS

Complete Setup Guide
完整设置指南

完整設定指南
설치 가이드




logitech®

CONTENTS



English	3	繁體中文	9
简体中文	6	한국어	12

KNOW YOUR PRODUCT





CONNECT THE SPEAKERS

1. Connect the USB-A power cable to your device for power and audio.
2. When the power is on, there will be an orange light signal on your right speaker.




ADJUST THE VOLUME

1. Increase (or decrease) the volume of speakers by pressing the + or - buttons.
2. Mute by pressing the middle button.





www.logitech.com/support/S150

了解您的产品





连接音箱

1. 将 USB-A 电源线连接到设备以获得电源和音频。
2. 开启电源后, 右侧音箱上会出现橙色信号灯。




调节音量

1. 按下 + 或 - 按钮可增加 (或减少) 音箱音量。
2. 按下中间按钮静音。





www.logitech.com/support/S150

瞭解您的產品





連接音箱

1. 將 USB-A 電源連接線連接到您的裝置，以傳輸電力和音訊。
2. 電源開啓時，右音箱上會亮起橙色訊號燈。




調整音量

1. 按下 + 或 - 按鈕可增加 (或減少) 音箱音量。
2. 按下中間按鈕可靜音。



www.logitech.com/support/S150


제품 설명




스피커 연결

1. 전원 및 오디오 사용 시 USB-A 전원 케이블을 장치에 연결합니다.
2. 전원이 켜지면 오른쪽 스피커에 주황색 불빛이 들어옵니다.

1





2





볼륨 조절

1. + 또는 - 버튼을 눌러 스피커의 볼륨을 높이거나 낮출 수 있습니다.
2. 음소거는 가운데 버튼을 누릅니다.

1



2



www.logitech.com/support/S150

www.logitech.com/support/S150

© 2019 Logitech. Logitech, Logi and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

WEB-621-001579.002

