


STEREO HEADSET H110

立体声耳机（含麦克风） H110

Setup Guide
设置指南




logitech®

CONTENTS


English	3	繁體中文	7
简体中文	5	한국어	9

KNOW YOUR PRODUCT




CONNECTING THE HEADSET

1. Plug the green 3.5 mm plug into the 3.5 mm headphone jack on your computer.
2. Plug the red 3.5 mm microphone plug into the 3.5 mm microphone jack on your computer.




HEADSET FIT


1. To adjust headset size, move the headband up and down until it fits comfortably.
2. Move the flexible microphone boom up or down and in or out until it is level with your mouth for better voice capture.
3. Boom can be tucked out of the way when not being used.




2



3




了解您的产品




连接耳机（含麦克风）

1. 将绿色的 3.5 毫米插头插入电脑的 3.5 毫米耳机插孔。
2. 将红色的 3.5 毫米麦克风插头插入电脑的 3.5 毫米麦克风插孔。




耳机（含麦克风）贴合佩戴


1. 要调节耳机（含麦克风）尺寸，请上下移动头带，直至佩戴舒适贴合。
2. 可上下及前后移动麦克风杆，直至与嘴部齐平，以便更好地捕捉声音。
3. 不使用时，可将麦克风杆旋转至不影响当前使用的位置。




2



3




瞭解您的產品




連接耳機（含麥克風）

1. 將綠色的 3.5 公釐插頭，插入到您電腦上的 3.5 公釐耳機插孔。
2. 將紅色的 3.5 公釐麥克風插頭，插入到您電腦上的 3.5 公釐麥克風插孔。




耳機麥克風配戴


1. 若要調整耳機麥克風大小，請上下移動頭帶直到可舒適配戴為止。
2. 上下、內外移動彈性麥克風桿，直到其與您的嘴部同高以獲得更好的收音。
3. 麥克風桿不使用時可以將其完全收合。




2



3




제품 설명




헤드셋 연결

1. 초록색 3.5mm 플러그를 컴퓨터의 3.5mm 헤드폰 잭에 연결합니다.
2. 빨간색 3.5mm 마이크 플러그를 컴퓨터의 3.5mm 마이크 잭에 연결합니다.




헤드셋 핏


1. 헤드셋 크기를 조정하려면 헤드밴드가 잘 맞을 때까지 위아래로 이동합니다.
2. 더 나은 음성 캡처를 위해 유연한 마이크 붐을 입과 수평이 될 때까지 위아래로 또는 바깥쪽으로 이동합니다.
3. 붐은 사용하지 않을 때 접어서 넣어둘 수 있습니다.



2



3



www.logitech.com/support/h110

© 2024 Logitech. Logitech, Logi, and their logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. All other 3rd party trademarks are the properties of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2024 罗技。罗技、Logitech、Logi 及其标志为 罗技欧洲公司 和/或其附属公司在美国及其他国家/地区的商标，并或已注册。所有其他第三方商标均为其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。图片仅作说明之用，可能与实物有所差别。

WEB-621-002568 002