

WIRING DIAGRAMS 2

27 October 2026











TABLE OF CONTENTS

Rally AI Camera Pro / Rally AI Camera	5
Rally Board 65	18
Rally Bar 2	27


Note: most diagrams on the following pages show Tap using a USB connection. However, in most configurations you may substitute a Tap IP or Tap IP 2 using one of the below connection methods.

Tap
USB connection




Note: most diagrams on the following pages show Tap using a USB connection. However, in most configurations you may substitute a Tap IP* or Tap IP 2** using one of the below connection methods.


Tap IP or Tap IP 2
LAN + PoE injector (available for purchase seperately)



Tap IP or Tap IP 2
PoE enabled network



Tap IP or Tap IP 2
WLAN + PoE injector (available for purchase seperately)



Tap IP or Tap IP 2


* Tap IP is not supported with Rally Bar 2 for Microsoft Teams Rooms on Android.
This combination is supported for Zoom Rooms on Android and Google Mete on Android
** Tap IP 2 is not supported with Rally Bar, Rally Bar Mini or RoomMate..

RALLY AI CAMERA PRO & RALLY AI CAMERA

Table of Contents








CAT
USB


Rally AI Camera Pro
PC Mode: Default configuration



CAT
USB


* Requires USB A to USB C cable or
USB C (f) to USB A (m) adapter, not included

Rally AI Camera Pro
Android Mode with RoomMate



CAT
USB


Rally AI Camera
PC Mode: Default configuration



CAT
USB


* Requires USB A to USB C cable or
USB C (f) to USB A (m) adapter, not included

Rally AI Camera
Android Mode with RoomMate




CAT
USB

Rally AI Camera / Rally AI Camera Pro
Rally AI Camera Extension Kit




CAT
USB
HDMI


* Requires USB A to USB C cable or
USB C (f) to USB A (m) adapter, not included



Compute
POWER
MIC POD
USB-A1
USB-A2
USB-A3
HDMI-IN
HDMI-OUT 1
HDMI-OUT 2
ETHERNET
USB-C
USB C
CAT
Tap

CAT
USB
HDMI




Rally Plus with Rally AI Camera Pro: compute at Display Hub. Up to 7 Mic Pod and 7 Mic Pod Hubs



Compute
HDMI
HDMI
USB
Display Hub
USB C
Tap
Table Hub
Speaker
CAT
USB
HDMI
MIC
CAT6a
Mic Pods



Rally Plus with Rally AI Camera Pro: compute at Table Hub. Up to 7 Mic Pod and 7 Mic Pod Hubs.




* Requires USB A to USB C cable or
USB C (f) to USB A (m) adapter, not included


Ethernet
HDMI 1 OUT
ROOMMATE
HDMI 2 OUT
Display Hub
Tap
Table Hub
Speaker
CAT
USB
HDMI
MIC
CAT6a
Mic Pods

RALLY BOARD 65


Table of Contents







CAT
Power

Rally Board 65
Android Mode
Ethernet connection


POWER
EXT
USB-A
USB-A
USB-A
HDMI-TV
HDMI-IN
USB-C
ETHERNET
LINE OUT




Power ■




CAT
USB

Rally Board 65 with Tap
Android Mode




CAT
USB
HDMI

Rally Board 65 and Tap with HDMI ingest
Android Mode




CAT
USB
HDMI

Rally Board 65 and Tap with External USB Camera
Android Mode



CAT
USB


Rally Board 65 with Logi Active USB Cable (5m)
BYOD Mode
Supports DisplayPort Alt Mode




* Requires USB A to USB C cable or
USB C (f) to USB A (m) adapter, not included


Rally Board 65 with Extend
BYOD Mode
Touchback support

Rally Board 65



Rally Mic Pod 2





Tap IP


CAT
USB
HDMI

* Link port on earlier production units, may be labeled EXT. No functional change.


RALLY BAR 2


Table of Contents






Rally Bar 2 with Tap IP 2



HDMI-TV1
CAT
USB
HDMI
Tap IP 2




Rally Bar 2 with Touch Screen



CAT
USB
HDMI


HDMI-TV1
HDMI-TV2
Compute
CAT
Tap
CAT
USB
HDMI


HDMI-TV1
HDMI-TV2
Up to 10m (32') CAT Cable
Up to 70m (230') CAT6 Cable
or 40m (130') CAT5e Cable
Tap
Rally Mic Pod 2
CAT
USB
HDMI