


A20 X

SETUP GUIDE | GUIDE D'INSTALLATION







ENGLISH	3
FRANÇAIS.	7
ESPAÑOL	11
PORTUGUÊS	15







XBOX SERIES X|S




PLAYSTATION / NINTENDO






Bluetooth®


1



2




3




USB

1




2




XBOX SERIES X|S


1




2



3




4




PLAYSTATION / NINTENDO


1




2




3




4




1




2



3




4




Bluetooth®


1



2




3




USB

1




2




XBOX SERIES X|S


1




2




3



4




PLAYSTATION/NINTENDO




PC CON WINDOWS | MAC


1




2



3




4




Bluetooth®


1



2




3




USB

1




2




XBOX SERIES X|S


1




2



3




4




PLAYSTATION/NINTENDO


1




2




3




4




1




2



3




4




Bluetooth®


1



2




3




USB

1



2





© 2025 Logitech. Logitech, Logitech G, and their logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. *Xbox* and their logos, are trademarks of the Microsoft Corporation. The *Bluetooth*® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. *Nintendo Switch* is a trademark of Nintendo of America, Inc. *PlayStation* is a trademark of Sony Interactive Entertainment Inc. *USB-C* and the USB logo are trademarks of USB Implementers Forum. All other trademarks are the property of their respective owners.

© 2025 Logitech. Logitech, Logitech G et leurs logos sont des marques commerciales ou déposées de Logitech Europe S.A. et/ou de ses sociétés affiliées aux États-Unis et dans d'autres pays. *Xbox* et ses logos sont des marques déposées de Microsoft Corporation. La marque et les logos *Bluetooth*® sont des marques déposées détenues par Bluetooth SIG, Inc. et sont utilisés par Logitech sous licence. *Nintendo Switch* est une marque déposée de Nintendo of America, Inc. *PlayStation* est une marque déposée de Sony Interactive Entertainment Inc. *USB-C* et le logo USB sont des marques déposées d'USB Implementers Forum. Toutes les autres marques déposées sont la propriété exclusive de leurs détenteurs respectifs.

WEB-621-002676 002