

A20 X

SETUP GUIDE



logitech




ENGLISH 3
繁體中文 7
한국어 11
INDONESIA 15




XBOX SERIES X|S


1




2



3




4




PLAYSTATION / NINTENDO


1




2




3




4




1




2



3




4




Bluetooth®


1



2




3




USB

1




2




XBOX SERIES X|S


1




2



3




4




PLAYSTATION / NINTENDO


1




2




3




4




1




2



3




4




藍牙®


1



2




3




USB

1




2




XBOX SERIES X|S


1




2



3




4




PLAYSTATION / NINTENDO


1




2



3




4




1




2



3



4




블루투스®


1



2



3




USB

1




2




XBOX SERIES X|S


1




2



3




4




PLAYSTATION / NINTENDO


1




2




3




4




1




2



3




4




Bluetooth®


1



2




3




USB

1



2





© 2025 Logitech. Logitech, Logitech G, and their logos are trademarks or registered trademarks of Logitech Europe S.A. and/or its affiliates in the U.S. and other countries. Xbox and their logos, are trademarks of the Microsoft Corporation. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Logitech is under license. Nintendo Switch is a trademark of Nintendo of America, Inc. PlayStation is a trademark of Sony Interactive Entertainment Inc. USB-C and the USB logo are trademarks of USB Implementers Forum. All other trademarks are the property of their respective owners.

WEB-621-002678 002